EN 358 Work Positioning Devices / Restrain Belts EN 354 / 355 EN 361 Full Body Harnesses EN 1496 / 1497 / 1498 Rescue Harness

Before each use:

- Harnesses should be issued on a personal basis & all relevant information kept in the Record Card.
- 2 Visually inspect the condition of: webbing, stitch patterns, and fittings.
 - If there is any abrasion, cuts, holes or burns to the webbing the item should be rejected.
 - If there is any corrosion, cracks, distortion or burs on the fittings the item should be rejected.
 - If there is any broken, worn, pulled, or unravelling stitches the item should be rejected.

During use:

- Use only safety lines or lanyards approved to the correct BS EN standards. 3
- 4 Anchor points should always be above the operator where possible & slack kept to a minimum.
- Fall Protection devices should be attached via a suitable connector / karabiner to either the front or rear 'D' rings for fall arrest. 5
- 6. Work positioning devices should only be attached to side 'D' rings.
- Never use side 'D' rings for fall arrest.
- When using work positioning equipment the lanyard should be passed around the anchorage & fastened to separate attachments on the 7. harness. The lanyard should be adjusted so that the fall is limited to 0.5m.

PSM2

Lanyard

- 8 Ensure the anchor point is in accordance to EN 795.
- 9. Clearance below the operator should be a minimum of 5.75m for a 2m absorbing lanyard, this is the potential extension plus operator body length. If in doubt, seek advice.
- 10. Protect all equipment from sharp objects. Work Positioning lanyards should be passed around anchorages which do not have sharp edaes.
- 11. Any type of Harness, Lanyard, or Work Positioning device should not be used in locations which have extremes of temperature & chemical contamination
- 12. Certain chemical substances may reduce a products ability to perform, if in any doubt seek advice.
- 13. Store all equipment in a dry & dust free environment, away from direct sources of heat & light.
- 14. Cleaning: Certain substances may be removed with a diluted solution of cleaner & warm water, not to exceed 40°C, Dry naturally away from direct sources of heat.
- Never modify or repair PPE equipment. If in any doubt, DO NOT USE. 15
- 16. Rescue Harnesses should only be used when un-hindered lifting is possible.

17. Fitting and Removal:

- Ensure all straps are not twisted.
- Lift harness by rear dorsal 'D' ring, pass arms through shoulder straps, as if putting on a jacket. A
- В If fitted with 2 side 'D' rings, tighten belt and ensure any loose webbing is secured.
- Pass each leg strap under legs and fasten to square link, tighten ensuring leg loops are not twisted and webbing emerges forward. С
- D. Tighten all straps according to comfort & secure loose webbing.
- Adjust dorsal 'D' to be between shoulder blades. E.
- F To remove, reverse steps E to A.

•If subjected to a fall or if the device is worn or damaged, or any other part of the unit is considered worn - DO NOT USE. Return the unit for service immediately.

- •The recommended service interval is 6 months from the date of first use.
- •If there is any doubt of the suitability of any PPE device, DO NOT USE

